

Humanware Victor Reader Stream Audible User Guide



Requirements & Tech Specs

- Windows XP or Vista
- **Audible Formats:** 4
- **Capacities Available:** external card up to 8 GB
- **Bookmarking:** Yes
- **Section Navigation:** Yes
- **Variable Playback Speed:** Yes
- **FM Radio:** No
- **Video:** No



Numeric Key Functions

1. Bookshelf if pressed, User Guide if pressed and held
2. Navigation element
3. Delete
4. Back
5. Where am I?
6. Forward
7. Menu
8. Navigation Element
9. Text-to-Speech / Recorded modes toggle
- 0: Info if pressed, Key Describer Mode if pressed and held

Star key (*): Cancel if pressed, Key pad Lock if pressed and held

Pound key (#): Confirm

How To's:

A. Playback: How do I locate/play Audible content on the device?

- Use the **2 key** and **8 key** to navigate by the heading marks provided in the Audible book or by Stream's 1, 5, or 10 minute Time Jumps.
 - If you are browsing the Bookshelf, the **Go to Page key** becomes a **Go to Book key**. This allows you to enter a relative book number on a given Bookshelf. This is useful for Bookshelves that contain many books.

B. Rewind/Fast-Forward: How do I rewind/fast-forward through my Audible content on the device?

1. Rewinding:

- a. Time Jump navigation can be selected using the **2 key**.
- b. Press the **4 key** to move Backward.
- c. The Time Jump interval can be set at 1, 5, 10 minutes using the **Menu key (7)**.

2. Fast-Forwarding:

- a. Time Jump navigation can be selected using the **8 key**.
- b. Press the **6 key** to move Forward.
- c. The Time Jump interval can be set at 1, 5, 10 minutes using the **Menu key (7)**.

C. Section Navigation: How do I use section navigation?

** The device must have **Ch. Mode** (chapter mode) turned on.*

1. Use the **2** and **8 keys** to choose a navigation level.
2. **Level 1** means chapter, **level 2** means section, and **level 3** means sub-section and so on.
3. First, choose a **navigation level** (chapter, page, etc.), using the **2** and **8 keys**.
4. Then use the **4** and **6 keys** to move backward and forward between elements at the selected level.
5. The **2** and **8 keys** will only announce the levels available for the book.

D. Playback Speed: How do I change the playback speed on the device?

1. Turn the device **on**
2. Press the **Power** button on the top left side to toggle volume, speed, or tone settings.
3. Use the **up/down arrows** on the left side just below the Power button to raise or lower the selected setting.
4. There is a **beep** to mark the upper and lower range of each control.
5. If the book is not playing, **STREAM** will announce the setting position.
6. For tone and speed there is also a **beep** to mark the **normal** or **0** position.

E. Bookmarking: How do I bookmark on the device?

- **Setting a bookmark:**

1. Press the **Bookmark key**, twice or until you hear "insert bookmark".
You may access this function by holding the **Bookmark key** down instead of pressing it twice.
2. Enter the number from **1** to **99998** to assign it a Bookmark Number
3. Press the **Pound key** to confirm or the **Play/Stop key** to confirm and start playback.

- **Going to a bookmark:**

1. Press the **Bookmark key**, once or until you hear “go to bookmark”.
2. Enter the **number** of the bookmark you wish to go to.
3. Press the **Pound key**
4. It will go to the bookmark and announce its number
5. Or, press the **Play/Stop key**

- **Bookmark List**

1. Press the **Bookmark key**, four times or until you hear “bookmark list”
2. Press the **4** key or **6** key to go from one bookmark to the next.
3. When you press the **key**, it will say the number of the next bookmark and start playing
4. Press the Pound key to confirm the current position and continue play.

- **Removing a bookmark:**

1. Press the **Bookmark key**, five times or until you hear ‘remove bookmark’.
2. Enter the **number** of the Bookmark you wish to remove.
3. Press the **Pound key** to confirm.
4. To **remove all** the Bookmarks in a book, first press the **Bookmark key** five times or until you hear ‘remove bookmark’
5. Press the **9 key** five times (enter number **99999**).
6. Press the **Pound key** to confirm.

